

Outsole Belt Flexing Test Apparatus TX-513



Detailed Description

Sole adhesive or suture zone in the surface of canvas, cloth tape and then set the wheels of this machine, start the wheels, shoe soles that are bent, bending, after a certain number to view the damage and fracture shoe case, in order to understand their resistance to bending properties.

Specifications:

While test: up to 6 soles

Counter: LCD, 0~999.999

Horsepower: AC1/2HP inverter motor

Volume: 129x75x70cm

Weight: 170kg

Power: 1 ϕ , AC220V, 3A