

Salinity Refractometers (GMK-510AC & 520AC)

1. DESCRIPTION OF THE INSTRUMENT



2. BEFORE MEASUREMENT

- WITH BATTERY REMOVER, TURN LEFT THE LID OF BATTERY COMPARTMENT (BACK SIDE).
- WATCHING +/- POLES CAREFULLY, PLACE BATTERY 9V 1EA IN IT.
- IF 'CAL' SIGN APPEARS IN LCD AND DISAPPEARS, THE INSTRUMENT IS READY TO MEASURE IN NORMAL CONDITION (**AUTOMATIC CALIBRATION**)
- WIPE 'SAMPLE WELL' WITH CLEAN WATER & TISSUE

3. MEASUREMENT

- PLACE TWO OR THREE DROPS OF TEST SAMPLE ENOUGH TO COVER THE PRISM OF SAMPLE WELL (# WHEN THE PRISM IS EXPOSED TO THE AIR OR IN CASE OF NO TEST SAMPLE ON THE SAMPLE WELL, 'Err' SIGN APPEARS ON LCD.).
- PLACE LIGHT COVER ON SAMPLE WELL AND PRESS MEASURE BUTTON.
- AFTER (---) SIGN FLICKERS THREE TIMES, MEASUREMENT RESULT APPEARS ON LCD FOR ABOUT TWO MINUTES.
- IF THE TEST SAMPLE IS OUT OF THE MEASURING RANGE, 'Err' SIGN APPEARS.

4. IMPORTANT

- BEFORE EVERY MEASUREMENT, CLEAN THE SAMPLE WELL WITH WATER & TISSUE.
- WHEN LOW BATTERY SIGN APPEARS, REPLACE THE BATTERY SHORTLY.
- AVOID DIRECT RAYS OF LIGHT AND DON'T STORE THE UNIT AT DAMP PLACE.
- IN CASE OF NO USE FOR A LONG TIME, MAKE SURE TO REMOVE THE BATTERY.
- WARRANTY PERIOD IS 12 MONTHS AFTER THE DATE OF PURCHASE.
- IN CASE OF WRONG USE, ABUSE OR MISUSE, WARRANTY WILL NOT BE GRANTED,

ACCESSORIES



Battery remover



Light cover



Bottle



Carrying bag

G-WON HITECH CO., LTD.

WOOLIM E-BIZ. CENTER 310,
#170-5, GURO-DONG, GURO-GU,
SEOUL, KOREA(152-769)
Tel : 82-2-2108-1646(DIR.)
Fax : 82-2-2108-1649
E-Mail : g-won@g-won.co.kr

Other Instruments

- | | |
|------------------------|--------------------------|
| ■ Grain Moisture Meter | ■ Coffee Moisture Meter |
| ■ Wood Moisture Meter | ■ Tobacco Moisture Meter |
| ■ Flour Moisture Meter | ■ Digital Salt Meter |
| ■ Tea Moisture Meter | ■ Fruit Acidity Meter |

[➤ BACK](#)
[➤ PRINT](#)
[☒ CLOSE](#)

